



Elektra plus G-spot

PRODUCT MANUAL

7 vibration modes


**5 electro-stimulation
impulse modes**

**Made from silicone
and ABS plastic**

Waterproof

Charging




- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 3 hours for 1 hour of play.



USB
charging port

How To Use

TO ENSURE CONNECTIVITY, PLEASE APPLY WATER-BASED LUBE TO THE AREA OF STIMULATION. IF THE SKIN IS TOO DRY, THE IMPULSE MIGHT NOT GO THROUGH

- Hold the  button to turn on/off.
- Press the  button quickly to cycle through 7 vibration modes.
- Press the  button to cycle through 5 electro-stimulation modes.



Cleaning and Care

- Use mild soap and water to clean the product.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



Warning

- **Consult your doctor before use if you have a heart condition/wear a heart monitor.**
- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352