

edénfantasys
THE NEW INTIMACY



Hammer X

PRODUCT MANUAL

10 massage modes

2 powerful motors

Made from silicone

Waterproof IPX7




Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 210 minutes for 80 minutes of play.
- Do not use the device while charging.



USB charging
port

How To Use

- Hold the  button to turn the toy on/off.
- Press the bottom  button to cycle through 10 massage modes for the shaft/handle.
- Press the top  button quickly to cycle through 10 massage modes for the clitoral end.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352