



Asana Kegel balls

PRODUCT MANUAL

Free-moving weighted balls

**Removable weights** 

**Discreet design** 

Made from silicone and ABS plastic





## **Cleaning and Care**

- Remove the balls for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.
- The item can be washed in a dishwasher.



## Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

## edénfantasys

## www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352