ed@nfantasys



Auto douche

PRODUCT MANUAL

3 spraying intensities

5 jet openings

Volume 11.8 fl.oz.

Ruler markings

Waterproof IPX6

Made from silicone, ABS plastic and PET

Charging

- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (the Computer must be turned on)
- The slow, intermittent glow indicates charging is in progress.
- A full charge takes up to 30 min for 70 min of use.
- Do not use the device while charging.



USB charging port

How To Use

- Unscrew the bulb counterclockwise.
- After filling with enough water, screw on the bulb clockwise.
- Hold the **U** button to turn the enema on/off.
- Press it quickly to cycle through 3 spray intensities.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys THE NEW INTIMACY

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352