

Auto Maximizer

PRODUCT MANUAL

This product is intended for adult use as a non-medical pleasure device only. Not for medical use. No medical claims are warranted or implied by the use of this product.

- **4 suction modes**
- **4 pumping speeds**
- **Voice commands**
- **Ruler marks**
- **Made from ABS plastic and silicone**



CHARGING

- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge takes up to 130 minutes for 55 minutes of play.
- Do not use the device while charging.

HOW TO USE

- Screw the base onto the cylinder tightly.
- Apply water-based lubricant to your shaft.
- Insert yourself, flaccid or semi-flaccid, into the donut at the base of the pump.
- Hold the  button to turn on/off.
- Press the  button quickly to cycle through 4 pumping speeds. The LED light stays on and changes color with each level.
- Press the  button to cycle through 4 suction modes. The LED light stays on and changes color with each level.

- Press the  button and the  button simultaneously to switch to the manual sucking mode. Hold the  button to build up suction, release to stop.
- Once the desired erection is achieved, stop pumping.
- Short press the  button to pause the current function.
- Press the same button again briefly to activate the air release (deflation) function.
- If pain or discomfort occurs, immediately release pressure by holding the  button or disassembling the base and the cylinder and discontinue use.

VOICE CONTROL COMMANDS

- To activate voice control, say: "Hello K"
- Wait for the sound prompt before giving a command.

● **Voice Commands**

"Turn Off" - Turns the device off

● **Pumping Modes**

"P one" - Pumping Mode 1

"P two" - Pumping Mode 2

"P three" - Pumping Mode 3

"P four" - Pumping Mode 4

● **Suction Modes**

"S one" - Suction Mode 1

"S two" - Suction Mode 2

"S three" - Suction Mode 3

"S four" - Suction Mode 4

● **Suction Control**

"Sucking" - Start suction

"Release" - Release pressure

● **Playback Control**

"Pause" - Pause operation

"Stop" - Stop current operation

- **Volume Control**

"Increase volume" - Make it louder

"Lower volume" - Make it quieter

- **Volume Levels**

The device has 5 volume levels.

When powered on, it starts at Level 3 by default.

The loudness can be adjusted by voice command.

When the maximum or minimum level is reached, the device will emit a sound prompt.

CLEANING AND CARE

- Unscrew the base from the cylinder.
- Remove the donut for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the cylinder and the donut before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Do not get water inside the motorized unit as it is not waterproof.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



PRECAUTIONS

- Apply only the minimum amount of vacuum pressure necessary to achieve an erection; overdoing it may bruise or injure the penis.

WARNING

- Stop using the vacuum pump if pain occurs.
- Do not use under the influence of alcohol or drugs, since it may impair the user's judgment and increase the risk of injury to the penis.
- Do not use if you have sickle cell disease, have a history of prolonged erections, or you are taking large quantities of aspirin or other blood thinners, as these conditions increase the risk of bruising and hematoma.
- Use of the device may bruise or rupture the blood vessels within the penis or scrotum, resulting in petechiae, hemorrhage, or the formation of a hematoma.
- Use of the device may aggravate already existing conditions such as Peyronie's disease (the formation of hardened tissue in the penis that causes pain, curvature, and distortion, usually during erection); priapism (persistent, usually painful erection of the penis as a consequence of disease and not related to sexual arousal); and urethral strictures (urethral stricture is an area of hardened tissue which narrows the urethra, sometimes making it difficult to urinate).
- Misuse of the vacuum pump could injure the penis.
- If you have symptoms of erectile dysfunction, i.e., inability to achieve an erection that is sufficient for sexual intercourse, consult your physician prior to using this device to avoid a potentially harmful delay in diagnosing any of the most common causes of this condition, such as diabetes, multiple sclerosis, cirrhosis of the liver, chronic renal failure, or alcoholism.
- Do not use the device if you have decreased sensation of pain in the area of the penis.
- Do not use the device if you have decreased hand strength because this may make removing the device difficult.

MANAGING COMMON PROBLEMS WITH A VACUUM DEVICE

Problem	Likely cause	Remedy	Comments
No erection	No vacuum because of air leak caused by poor seal	Use more lubricant; apply firm pressure to the body; trim pubic hair; check the device for air leaks	Problem is most often associated with inexperience; it resolves as you become more adept at using the device
Partial erection	Incorrect cylinder size; incorrect insert or seal ring size; not enough practice sessions	More practice using device; use larger cylinder insert	Problem most often improves with continued use of device
Rapid loss of erection (in less than 5 minutes)	Vacuum lost because of air leak from faulty equipment, poor seal, inadequate lubrication, or excessive pubic hair	Same as for "No erection." Also: use smaller cylinder insert; use smaller or double tension rings; remove tension band carefully	Requires that you experiment with varying sizes of seal rings, inserts, and tension bands; see your physician if you need help or support to persevere
Delayed loss of erection (after 5 to 10 minutes)	Insufficient tension from bands or rings	Use smaller or combination of tension rings or bands; use the two-step application method (ask your physician about this)	
Pulling of the skin of the scrotum	Lubricant on scrotum; improper pumping technique; too large insert or seal ring; inexperience with system	Remove lubricant from scrotum; use smaller insert or seal ring; use the modified pumping technique (ask your physician about this); continue with practice sessions; angle cylinder downward during pumping	Problem may disappear as you become more adept at using the device.
Discomfort or pain:			
During pumping	Too rapid pumping; pulling of scrotal tissue	Slower pumping; continue to use device	Problem usually resolves as you become more adept at using the device
From tension ring	Tension ring too small; Anxiety	Use larger tension ring; continue to use device	Problem usually resolves as you continue to use the device
During intercourse	Inadequate lubrication; pressure on a sensitive area	More lubrication; position changes	
During ejaculation	Long period of abstinence; infection or inflammation of the prostate gland	Discontinue using device, consult your physician	
Redness, irritation, or bruising	Too rapid pumping; over pumping	Slower pumping; fewer pumps	Consult your physician if this problem persists past the first few practice sessions
Penis feels cold (to you or your partner)	Constriction of blood flow to the penis; lubrication	Wash off lubricant or warm lubricant before use	
Penis pivots on its base	Constriction of blood flow to the penis	If manageable, apply the device after you have a partial erection	



Customer Service 10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352



www.edenfantasys.com