ed@nfantasys



Auto Male Sucker

PRODUCT MANUAL

7 sucking modes

7 vibration modes

Made from TPE and ABS plastic

Charging

- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 2.5 hours for 1.5 hours of play.
- Do not use the device while charging.



Type-C charging port

How To Use

- Hold the 🖒 button to turn on/off.
- Press the button quickly to cycle through 7 sucking modes.
- Hold the button to pause suction.
- Press the W button quickly to cycle through 7 vibration modes.
- Hold the W button to turn vibration off.



Cleaning and Care

- Carefully remove the motor from the sleeve
- Use a toy cleaner/mild soap with water to clean the sleeve before and after each use.
- Pat the sleeve with a towel and allow it to air-dry completely.
- Dust lightly with talc or cornstarch for better use. Store away from heat and sunlight.
- Insert the motor inside the sleeve.





- Use with water-based lubes only, no silicone lubricants.
- Store away from other toys to avoid chemical reactions and damage to either toy.

Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352