edénfantasys



Big O wheel

PRODUCT MANUAL

Oral sex imitating clit attachment

G-spot stimulating head

3 modes of tongues rotation

10 vibration modes

Waterproof

Made from silicone and ABS plastic

Power

- The item is powered by 2 AAA batteries.
- Unscrew the base of the item to insert batteries.
- Follow the polarity instructions inside the battery case.



2 AAA batteries

How To Use

- Hold the 🖒 button to turn on/off.
- Press the *W* button quickly to cycle through 10 modes.
- The rotating tongues will be activated along with the vibration modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352