edénfantasys



Up to 200 thrusts per minute

Hands-free construction

Bendable dildo attachment

Realistic masturbator attachment

Adjustable angle

Made from ABS plastic, metal and skin-like TPR material



PRODUCT MANUAL


Set includes

 Sex machine, realistic dildo attachment, masturbator attachment, control pack, electric cord and adapter (works on 100-240V), 4 suction cups.



Power

- The sex machine is powered by an electric cord.
- Connect the included electric cord to the sex machine (MOTOR jack).
- Insert the plug into the socket to activate the toy.
- Keep the toy plugged in to enjoy the play.



Before Use

 Screw the attachment onto the rod and secure it with the locking nut.



• Screw on the 4 suction cups and attach the machine to a smooth horizontal surface.



Suction cup

- Adjust for a comfortable angle via tension knobs.
- Adjust the position of the handle via the tension knob (360°).

Tension knobs



How To Use

- Connect the control pack to the sex machine, large connector into DC24V OUT jack, small connector into DC24V IN jack.
- Before turning the machine on, make sure the control pack is turned off.
- Once all the pieces are attached, connect the included electric cord to the sex machine (MOTOR jack).
- Insert the plug into the socket to activate the sex machine.
- Rotate the dial control on the control pack to cycle through multiple thrusting speeds.



Cleaning and Care

- Remove the attachment for thorough cleaning.
- Do not wash the attachment while it is connected to the sex machine, so as not to damage metallic details.
- Do not wash the attachment on the sex machine while the power is on.
- Use a toy cleaner/mild soap with water to clean the attachment before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Do not let the water get inside the sex machine and control pack as they are not waterproof. Wipe the machine and the control pack down with a wet cloth/tissue and dry it out completely.
- Put the attachment on to finish the assembly.
- Dust lightly the realistic attachments with corn starch or talc for better use and store away from heat and sunlight.
- Use with water-based lube only, no silicone lubricants.

Warning

• The sex machine can not be used for more than 40 mins at a time, since it may shorten the lifespan of the machine.

- Do not sit on the machine and do not put any other pressure on it while it's working, since it may damage the machine and cause its malfunction.
- The machine has protection from overheating. If it is used continuously for a long time, the machine will stop abruptly if it overheats. This is normal, and the machine will automatically restart after cooling down.
- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352