



Bouncing vibrator

PRODUCT MANUAL

Multi-speed vibrations

Realistic design

Inflatable cushion

**Made from
phthalate-free PVC
and ABS plastic**

Power


- The control pack is powered by 2 AA batteries.
- Open the lid of the control pack to insert the batteries.
- Follow the polarity instructions inside the battery case.



2 AA
batteries

How To Use

- Inflate the cushion for extra support (pump not included).
- Rotate the dial control to turn vibration on/off.
- Adjust the dial control to increase/ reduce the vibration intensity.



Dial control

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with talc or cornstarch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.
- Store away from other toys to avoid chemical reactions and damage to either toy.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352