edénfantasys



Catalyst rimming P-spot massager

PRODUCT MANUAL

Ergonomic design

12 vibration modes

3 beads rotation modes

Made from silicone and ABS plastic

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 3 hours for 1 hour of play.



USB charging port

How To Use

- Insert with the external arm on the perineum, facing the testicles.
- Hold the **W** button to turn the vibration on/off.
- Press it quickly to cycle through 12 vibration modes.
- Hold the
 button to turn the rotation of the beads on/off.
- Press it quickly to cycle through 3 beads rotation modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352