



Concerto

PRODUCT MANUAL

4 sucking modes

9 licking and vibrating modes on the tongue

9 vibrating modes

3 independent motors

Removable suction cup

Waterproof IPX7

Made from silicone and ABS plastic

Charging


- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow, intermittent glow indicates charging in progress.
- A full charge takes up to 140 minutes for 45 minutes of play.



Magnetic charging port

How To Use

- Hold the  button to turn vibration on/off. The LED light will light up.
- Press it quickly to cycle through 9 vibration modes on the shaft.
- Hold the  button to turn suction on/off. The LED light will light up.
- Press it to cycle through the 4 suction modes.
- Hold the  button to turn vibration and licking on/off. The LED light will light up.
- Press it to cycle through the 9 vibration and licking modes on the tongue.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with the towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352