



Connection Dolce

9 thrusting modes

9 massage modes

App operated

Waterproof IPX6

Made from silicone
and ABS plastic

PRODUCT MANUAL


Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The intermittent glow indicates charging in progress.
- A full charge takes up to 3 hours for 50 minutes of play.
- Do not use the device while charging.

How To Use

- Hold the  button to turn the toy on/off.
- Press it quickly to cycle through 9 thrusting and massage modes.

Magnetic USB charging port



App operation

- Download the **Love Spouse** app from Google Play or App Store (the app is free).






QR code:

- Open the app on your phone and accept the User Agreement.
- Log in to your account or register a new one.
- The app will request access to **Bluetooth, Camera, Album, and Microphone** - please allow access in your phone settings.
- Tap the **+** to add a new device - this will connect the toy to your phone.
- Scan the QR code of your toy via the app. You can also add your device by entering the product code 2534.



QR code:

App operation

- In the “**Classic mode**” tab, you can select the pattern you like the most.
- You can create your own pattern by tapping on  and recording a new one by tapping the screen in your preferred rhythm. Press the  to delete the recorded pattern. Press **start/pause** to turn **on/pause** the recording mode. Press the  to save the new pattern.
- Press the  to enter your own pattern list and choose one to play.
- Enter the “**Game mode**” tab to enjoy a massage while you play a game. When the same fruits in the game touch each other, the vibration of the toy activates. The bigger the fruit, the stronger the vibration.
- In “**Video mode**”, you can choose a local video on your phone by tapping the button “**Select local video**”. Select the pattern you like the most.
- In the “**Musical mode**” tab, you can sync up the music playing on your phone (via any app) and the vibration of the toy. Just tap the “Start listening” button. Please note that you have to be in the “**Musical mode**” tab in the app for the toy to begin picking up music and activate.
- In the “**Draw something**” tab, you can control the toy’s vibration by tracing visual drawing lines on the screen.
- In the “**Shake it**” tab, you can control the vibration of the toy by shaking your phone in the desired rhythm and potency.

- In the “**Interactive mode**” tab, you can add contacts to the list of people who can control your toy through the app. Tap “**Add friend using ID**” to add a new friend. Choose a contact from your contact list to create a playroom. Pick a type of interaction you want: video chat or voice chat.
- After you both enter the playroom, the other user will be able to connect to your toy, and you will be able to control their devices, too.

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lubes only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.

Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352