



**6 massage modes**

**App operated**

**Waterproof IPX5**


**Made from silicone and ABS plastic**

**Connection  
love nips**

**PRODUCT MANUAL**

## Charging

- For maximum pleasure charge before every use.
- Connect to the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress. A full charge takes up to 3 hours for 1 hour of play.
- Do not use the device while charging.




Power button

Magnetic USB charging port



## How To Use

### Without remote control

- Hold the  button to turn on/off.
- Press it quickly to cycle through 6 massage modes.

LIMIT THE USE OF THE NIPPLE CLAMPS TO NO LONGER THAN 15 MINUTES PER USE.

### With the remote control

- Hold the  button on the toy to activate the standby mode.
- Press  button on the remote to turn the toy on/off.
- Press the + / - buttons on the remote quickly to cycle through 6 massage modes.

## App operation

- Download the **Love Spouse** app from Google Play or App Store (the app is free).




QR code:











- Open the app on your phone and accept the User Agreement.
- Log in to your account or register a new one.
- The app will request access to **Bluetooth, Camera, Album, and Microphone** - please allow access in your phone settings.
- Tap the **+** to add a new device - this will connect the toy to your phone.
- Scan the **QR code** of your toy via the app. You can also add your device by entering the product code **4520**.

QR code:



- Choose your preferred style of control: personalized or routine.
- Tap the device picture on the app's homepage to begin playing.
- In the **"Classic mode"** tab, you can select the pattern you like the most.
- You can create your own pattern by tapping on  and recording a new one by tapping the screen in your preferred rhythm . Press the  to delete the recorded pattern. Press **start/pause** to turn on/pause the recording mode.
- Press the  to save the new pattern.

- Press the  to create your own pattern list and choose one to play. Enter the **"Game mode"** tab to enjoy a massage while you play a game. When two of the same fruits in the game touch each other, the toy's vibration activates. The bigger the fruit, the stronger the vibration.
- In **"Video mode"**, you can choose a local video on your phone by tapping the button **"Select local video"**. Select the pattern you like the most.
- In the **"Musical mode"** tab, you can sync the music playing on your phone (via any app) with the vibration of the toy. Just tap the **"Start listening"** button. Please note that you have to be in the **"Musical mode"** tab in the app for the toy to begin picking up music and activating.
- You can create your own pattern to the rhythm of the music by tapping on  and begin recording, matching your tapping to the tune. Press the  to delete the recorded pattern.
- Press **start/pause** to turn **on/pause** the recording mode. Press the  to save the new pattern.
- In the **"Draw something"** tab, you can control the toy's vibration by tracing visual drawing lines on the screen.
- You can create your own pattern by tapping on  and putting the vibration mode into visuals - dots and lines or whatever else you want to draw to illustrate the desired vibration pattern. Press the  to delete the recorded mode. Press the **start/pause** to turn **on/pause** the recording pattern. Press the  to save the new pattern.
- In the **"Shake it"** tab, you can control the vibration of the toy by shaking your phone in the desired rhythm and potency.

- In the **"Interactive mode"** tab, you can add contacts to the list of people who will be able to control your toy through the app.
- Tap  to add a new friend. Please note that your friend needs to also have an account in the app.
- Choose a contact from your contact list to create a playroom. Pick a type of interaction you want: video chat or voice chat.
- After you both enter the playroom, the other user will be able to connect to your toy, and you will be able to control their devices, too.
- In the **"Classic mode"** tab, you may choose a pattern for them.
- In the **"Draw something"** tab, you can control the vibration of their toy by drawing lines on the screen.
- In the **"Shake it"** tab, you can control the vibration of their toy by shaking the phone.
- In the **"Type what you want to say"** field, you can send messages to your contacts during the game.

## Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.

## Warning

- Do not use on inflamed and injured areas. Discontinue use if feeling pain or discomfort.
- Limit the use of the nipple clamps to no longer than 15 minutes per use.

- Allow at least 60 mins between uses as more frequent use may increase the risk of injury to the nipples.
- Do not use the nipple clamps under the influence of alcohol or drugs, since it may impair the user's judgment and increase the risk of injuring the nipples.
- Misuse of nipple clamps may cause bruising, painful injury, or permanent damage to the nipples.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

## Precautions

- Incorrect use of this device may bruise or rupture the blood vessels within the nipples, resulting in petechiae (a small purplish spot on a body surface, such as the skin or mucous membrane, caused by a minute hemorrhage), hemorrhage (flow of blood from ruptured blood vessels), or the formation of a hematoma (localized swelling filled with blood resulting from a break in a blood vessel).

**edenfantasys**  
THE NEW INTIMACY

[www.edenfantasys.com](http://www.edenfantasys.com)

Customer Service  
10 AM - 7 PM EST  
Phone: 1 (770) 604 - 1352