### edénfantasys



# Couple's delight

PRODUCT MANUAL

#### Power

2 fun shapes

12 vibration modes

Made from silicone

- Insert 2 AAA batteries to power the control pack.
- Unscrew the base of the control pack to insert the batteries.
- Follow the polarity instructions inside the battery case.



#### **How To Use**

- Press the 😃 button to turn on/off.
- Press the **W** button to cycle through 12 vibration modes.



#### **Cleaning and Care**

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



#### Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

## edénfantasys

#### www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352