edénfantasys



Doggie pussy and ass

PRODUCT MANUAL

Realistic design

Anal and vaginal canals

2 powerful motors

Features seductive moans

Made from skin-like TPR material and ABS

Power

- Insert 3 AAA batteries to power the control pack.
- Open the lid to insert the batteries.
- Follow the polarity instructions inside the battery case.



How To Use

- Insert the bullets in the openings at the back of the masturbator.
- Press the left button to turn the vibration on/off.
- Press the right button to turn the seductive moans on/off.



Power button

Cleaning and Care

 Remove the bullets for thorough cleaning.

Use a toy cleaner/mild soap with

- water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.
- Do not get water inside the bullets and control pack as they are not waterproof.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352