edenfantasys



Double indulgence

PRODUCT MANUAL

Triple stimulation

2 powerful motors

6 vibration speeds

Bendable shafts

Made from soft TPR material and ABS plastic

Splashproof

Power

- The item is powered by 3 AAA batteries
- Unscrew the base to insert the batteries.
- Follow the polarity instructions inside the battery case.



How To Use

- Press the + button to turn on.
- Press the + or buttons to adjust vibration intensity.
- Press the button multiple times until the toy turns off.



button

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352