



# Dual bead waterproof rabbit

**PRODUCT MANUAL**

---

**5 vibration speeds**

---

**5 beads' rotation  
speeds**

---

**Made from soft TPR  
material**

---

**Waterproof**

## **Power**

---

- The item is powered by 4 AAA batteries.
- Unscrew the base to insert the batteries.
- Follow the polarity instructions inside the battery case.



4 AAA  
batteries

## How To Use

---

- Hold the **R/S** button to turn on/off.
- Press the **+** button to increase vibration or rotation intensity.
- Press the **-** button to decrease vibration or rotation intensity.
- Press the **R/S** to change the direction of beads' rotation.



Power Button

## Cleaning and Care

---

- Use a toy cleaner/mild soap with water to clean the product.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



## Warning

---

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

**edenfantasy**  
THE NEW INTIMACY

[www.edenfantasy.com](http://www.edenfantasy.com)

Customer Service 24/7  
Phone: +1 (770) 604 - 1352