## edenfantasys



**Dual** pleasure

PRODUCT MANUAL

### **Double vibrating eggs**

20 vibration modes

Made from velvety plastic

#### **Power**

- The item is powered by 2 AAA batteries
- Open the lid to insert the batteries.
- Follow the polarity instructions inside the battery case.



**batteries** 

#### **How To Use**

- Press the **b** button on the control pack to turn on/off.
- Press the W button to cycle through 20 vibration modes.



#### **Cleaning and Care**

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based, silicone, or oil-based lubricants.



#### Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

# edenfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352