



# Dual Rose

PRODUCT MANUAL

---

**10 sucking modes**

---

**10 thrusting modes**

---

**Splashproof**


---

**Made from silicone  
and ABS plastic**

## Charging

---



- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge takes up to 150 minutes for 60 minutes of play.
- Do not use the device while charging.




Magnetic  
USB charging port

## How To Use

---

- Hold the  button to turn on/off for standby mode. The LED light will light up.
- Press it quickly to cycle through 10 thrusting modes.
- Press the  button quickly to cycle through 10 sucking modes.



## Cleaning and Care

---

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lubes only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.

## Warning

---

- Do not submerge - the toy is splash-proof but not waterproof.
- Keep water from entering the air-sucking opening as it will damage the product.
- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

**edenfantasy**  
THE NEW INTIMACY

[www.edenfantasy.com](http://www.edenfantasy.com)

Customer Service 10 AM - 7 PM EST  
Phone: + 1 (770) 604 - 1352