



Dual Pleaser

PRODUCT MANUAL

30 massage modes


**Tongue licking
clit attachment**

Splashproof

**Made from silicone
and ABS plastic**



Power

- The item is powered by 2 x AAA batteries (not included).
- Unscrew the base of the item to insert the batteries.
- Follow the polarity instructions inside the battery case.



2 x AAA
batteries

How To Use

- Hold the  button to turn the toy on/off.
- Press the  button to cycle through 30 massage modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service
from 10 AM to 7 PM EST.
Phone: +1 (770) 604 - 1352