edénfantasys



Easy vibes

PRODUCT MANUAL

Power

Multispeed vibrations

Powerful motor

Made from ABS plastic

- Insert 2 AA batteries to power the control pack.
- Open the lid to insert the batteries.
- Follow the polarity instructions inside the battery case.



How To Use

- Rotate the dial control to turn on/off.
- Adjust the dial control to increase/reduce the vibration intensity.



Dial control

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water, silicone or oil-based lubricant.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

Customer Service 24/7 Phone: +1 (770) 604 - 1352

edén fantasys

www.edenfantasys.com