



Eden handsfree vibrating masturbator

PRODUCT MANUAL

30 vibration modes

Realistic opening

**Multi-angle suction
cup base**

**Made from skin-like
TPR material and ABS
plastic**

Power

- The item is powered by 4 AAA batteries.
- Unscrew the base to insert batteries.
- Follow the polarity instructions inside the battery case





4 AAA
batteries

Before Use

- Take the cap off to begin play.
- Pull the latch down to secure the suction cup.
- Adjust for a comfortable angle.

How To Use

- Press the  button to turn on/off.
- Press the  button quickly to cycle through 30 vibration modes.



Cleaning and Care

- Take the sleeve out of the plastic case for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the sleeve before and after each use.
- Pat the sleeve with a towel and allow it to air-dry completely.
- Do not get water inside the case as it is not waterproof. Wipe it down with the wet cloth/tissue and dry it out completely before inserting the sleeve.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352