



Eden lover's tongue 10 functions

PRODUCT MANUAL

10 vibration modes

Tongue-like design

Soft pleasure nubs

Removable bullet

Waterproof

**Made from soft TPR
and ABS plastic**

Power

- The item is powered by 3 LR44 batteries (included).
- Unscrew the base of the bullet to insert the batteries.
- Follow the polarity instructions inside the battery case.



3 LR44
batteries

How To Use

- Press the button to turn on/off.
- Press it quickly to cycle through 10 vibration modes.
- Wear on any finger to power up your touch.



Power
button

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Please do not submerge the toy in the water.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352