edénfantasys



Eden velvet G-spot vibrator

PRODUCT MANUAL

Discreet design

Powerful vibrations

Made from PU-coated plastic

Power

- The item is powered by 1 AA battery.
- Unscrew the base of the item to insert the battery.



How To Use

• Rotate the dial base to turn on/off.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product.
- Pat with a towel and allow it to air dry completely.
- Use with water, silicone or oilbased lubricant.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352