edénfantasys



Wild bunny with rotating beads

PRODUCT MANUAL

7 vibration modes

6 beads' rotation intensities

Made from soft TPR material

Power

- The item is powered by 4 AA batteries.
- Open the lid to insert the batteries.
- Follow the polarity instructions inside the battery case.



⁴ AA batteries

How To Use

- Press the top button to turn on/off.
- Press the **7** button quickly to cycle through vibration modes.
- Press the + button to increase rotation intensity.
- Press the button to reduce rotation intensity.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352