



Eden Mini Pleasure Bullet

PRODUCT MANUAL

10 massage modes

Quiet & powerful motor

Waterproof

Made from PU coated plastic

Power

- The item is powered by 3 LR44-3 batteries (included).
- Unscrew the base of the bullet to insert the batteries.
- Remove the protective film from the battery compartment before use.



How To Use

- Hold the button to turn on/off.
- Press it quickly to cycle through 10 massage modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based, silicone, or oil-based lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

Customer Service from 10 AM to 7 PM EST. Phone: +1 (770) 604 - 1352

edénfantasys

www.edenfantasys.com