


edenfantasys
THE NEW INTIMACY



**Eden
silicone
butterfly**

PRODUCT MANUAL

12 vibration modes

**Made from silicone
and ABS plastic**

Waterproof

Power

- Insert 2 AAA batteries to power the control pack.
- Unscrew the base of the control pack to insert the batteries.
- Follow the polarity instructions



2 AAA batteries

How To Use

- Press the **ON/OFF** button to activate/deactivate the vibration.
- Press the **12** button to cycle through vibration modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Do not get water inside the control pack it is not waterproof.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352