



Ego X

PRODUCT MANUAL

7 stroking modes

Seductive voice mode

Realistic opening

**Multi-angle suction
cup base**

**Made from skin-like
TPE material and
ABS plastic**

Charging


- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 3 hours for 1 hour of play.





USB charging port
& Headphone jack

Before Use

- Screw the suction cup stand into the mounting hole.
- Mount the suction cup stand to a flat surface.
- Pull the latch down to secure the stand.
- Secure in a comfortable angle with a tension knob.
- Take the cap off to begin play.



How To Use

- Hold the  button to turn on/off.
- Press it quickly to cycle through 7 stroking modes.
- Hold the  button to activate or deactivate the seductive voice mode.

Cleaning and Care

- Take the sleeve out of the plastic case for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the sleeve before and after each use.
- Pat the sleeve with a towel and allow it to air-dry completely.
- Do not get water inside the case as it is not waterproof. Wipe it down with the wet cloth/tissue and dry it out completely before inserting the sleeve.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352