edénfantasys



Elektra

PRODUCT MANUAL

2 e-stim impulse intensities

Adjustable e-stim impulse power

E-stim impulse mode for the control pack

Made from metal and ABS plastic

Power

- The control pack is powered by 1 CR2032 battery (included).
- Open the lid to insert the battery.

How To Use

- Before starting, make sure the power dial is on the **OFF** position.
- Insert the attachment contact pin into the control pack.
- Affix the pads onto the desired area.

ALWAYS LUBRICATE THE AREA TO ENSURE CONNECTIVITY. IF THE SKIN IS TOO DRY, THE IMPULSE MIGHT NOT PASS.

 Rotate the ► | OFF power dial on the control pack to turn the toy on\off and to adjust power of the electro-impulses.



 Slide the SLOW / FAST switch of the control pack to choose the electroimpulse intensity.



- Slide the switch to the IN position to activate the e-stim mode for the control pack. E-stim impulses will be transferred through the metal plate on the control pack.
- Slide the switch to the **OUT** position to return to the e-stim gel pads attachments.



• If pain or discomfort occurs, immediately remove the toy.

Cleaning and Care

- Remove the gel pads from the control pack.
- Do not let the water get inside the control pack since it is not waterproof. Wipe the control pack down with a wet cloth/tissue and dry it out completely.
- Use a toy cleaner/mild soap with water to clean the gel pads before and after each use.
- Pat with a towel and allow it to airdry completely.
- Use with the water-based lube only, no silicone lubricants.

• When storing for an extended period, please remove batteries from the device.



Warning

- Please consult your doctor before use if you have a heart condition or wear a heart monitor. We do not recommend using this or any other electro-stimulation toys.
- Do not turn it on in/near water.
- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352