edénfantasys



Elektra rings

2 e-stim impulse intensities

Adjustable e-stim impulse power

E-stim impulse mode for the control pack

Made from silicone, metal and ABS plastic

PRODUCT MANUAL

Power

- The control pack is powered by 1 CR2032 battery (included).
- Open the lid to insert the battery.

Cleaning and Care

- Remove the rings from the control pack.
- Do not let the water get inside the control pack since it is not waterproof. Wipe the control pack down with a wet cloth/tissue and dry it out completely.
- Use a toy cleaner/mild soap with water to clean the rings before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lube only, no silicone lubricants.
- When storing for an extended period, please remove the batteries from the device.

How To Use

- Before starting, make sure the power dial is on the **OFF** position.
- Insert the contact pin of the product into the control pack.
- Wear around the penis or penis and testicles.

ALWAYS LUBRICATE THE AREA TO ENSURE CONNECTIVITY. IF THE SKIN IS TOO DRY, THE IMPULSE MIGHT NOT PASS

 Rotate the >/OFF power dial on the control pack to turn the toy on/off and to adjust the intensity of the electro-impulses.



 Slide the SLOW/FAST switch of the control pack to choose the electro-impulse intensity.



- Slide the switch to the IN position to activate the e-stim mode for the control pack. E-stim impulses will be transferred through the metal plate on the control pack.
- Slide the switch to the **OUT** position to return to the cock rings.



• If pain or discomfort occurs, immediately remove the constriction rings.

LIMIT THE USE OF THE CONSTRICTION RING TO NO LONGER THAN 30 MINUTES PER USE

Warning

- Please consult your doctor before use if you have a heart condition or wear a heart monitor. We do not recommend using this or any other electro-stimulation toys.
- Do not turn it on in/near water.
- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Limit the use of the penis rings to no longer than 15 minutes per use.
- Allow at least 60 mins between uses as more frequent use may increase the risk of injury to the penis.
- Do not fall asleep while wearing the rings since prolonged use may cause injury to the penis.
- Do not use the constriction rings under the influence of alcohol or drugs, since it may impair the user's judgment and increase the risk of injury to the penis.
- Misuse of a constriction rings may cause bruising, painful injury, or permanent damage to the penis.
- Constriction rings do not prevent pregnancy.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

Precautions

- Use of a cock rings may aggravate already existing conditions such as Peyronie's disease (the formation of hardened tissue in the penis that causes pain, curvature, and distortion, usually during erection); priapism (persistent, usually painful erection of the penis as a consequence of disease and not related to sexual arousal); and urethral strictures (urethral stricture is an area of hardened tissue, which narrows the urethra sometimes making it difficult to urinate).
- Prolonged use of the constriction ring (i.e., without removal) may cause permanent injury to the penis.
- Incorrect use of this device may bruise or hurt the blood vessels within the penis or scrotum, resulting in petechiae (a small purplish spot on a body surface, such as the skin or mucous membrane, caused by a minute hemorrhage), hemorrhage (flow of blood from ruptured blood vessels), or the formation of a hematoma (localized swelling filled with blood resulting from a break in a blood vessel).
- Use the least constricting ring size that maintains your erection, since excessive constriction could injure the penis.

edénfantasys

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352