ed@nfantasys



Evolution XL

PRODUCT MANUAL

Product Features

6 vibration modes

3 rotation speeds

The tunnel heats up to 108°F

Made from silicone

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 3 hours for 1 hour of play.



How To Use

- Hold the **W** button to turn on/off.
- Press the button quickly to cycle through 6 vibration modes.
- Hold the button to turn the rotation on/off.
- Press the button quickly to cycle through 3 rotation speeds.

Heating

- Hold the button to turn the heating on/off.
- Allow up to 5 mins for the inner tunnel to warm up.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352