



Fantasy Thruster

PRODUCT MANUAL

**7 thrusting and
massage modes**


Heats up to 107° F

**Made from Silicone
and ABS plastic**

Splashproof


Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 3 hours for 1 hour of play.



Magnetic
Charging Port

How To Use

- Hold the  button to turn on/off.
- Press it quickly to cycle through 7 thrusting and massage modes.
- The heating function is activated once the toy is turned on.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with the towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult Novelty Only. Use for medical purposes or use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com