ed@nfantasys



Gold play

10 massage modes

Quiet and powerful motor

Splashproof

Made from ABS plastic

Power

- The item is powered by 1 AAA battery (included).
- Unscrew the base of the bullet to open the battery compartment.
- Follow the polarity instructions inside the battery case.



How To Use

- Hold the button to turn on/off.
- Press it quickly to cycle through 10 massage modes.



Power Button

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based, silicone, or oil-based lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys THE NEW INTIMACY

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352