edénfantasys



Handheld robo juicer

Stroking beaded rings 6 stroking and massage modes

2 powerful motors

Open-end style

Made from skin-like TPE material and ABS plastic

PRODUCT MANUAL

Charging

- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 150 minutes for 70 minutes of play.
- Do not use the device while charging.



How To Use

- Take the caps off to start playing.
- Hold the 🙂 button to turn the toy on/off.
- Press the I button quickly to cycle through 6 stroking and massage modes.
- Press the 🙂 button once to pause the motion.
- Press it again to unpause the motion.



Cleaning and Care

- Remove the caps.
- Take the sleeve out of the plastic case for thorough cleaning.



- Carefully remove the 2 corded bullets from the sleeve.
- Use a toy cleaner/mild soap with water to clean the sleeve before and after each use.



- Pat the sleeve with a towel and allow it to air-dry completely.
- Dust lightly with talc or cornstarch for better use. Store away from heat and sunlight.
- Wipe it down with a wet cloth/tissue and dry it out completely before inserting the sleeve.

- Insert the bullets into the holes inside the sleeve.
- Insert the sleeve into the plastic case to finish the assembly.



- Do not get water inside the case as it is not waterproof. Wipe it down with a wet cloth/tissue and dry it out completely before inserting the sleeve.
- Use with water-based lubes only, no silicone lubricants.
- Store away from other toys to avoid chemical reactions and damage to either toy.

Warning

- Do not use on inflamed and/or injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes and/or use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352