



Heartthrob

PRODUCT MANUAL

Thrusting head

4 thrusting modes

Heats up to 131° F

Travel lock

Waterproof

**Made from silicone
and ABS plastic**



Charging

- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow, intermittent glow indicates charging in progress.
- A full charge takes up to 2 hours for 50 min of play.




Magnetic
charging port


How To Use


- Press the  button to turn on.
- Press it quickly to cycle through 4 thrusting modes.
- Hold the  button to turn off.

Heating

- Press the  button to turn the heating on/off.
- Allow up to 5 mins for the toy to warm up.

Travel Lock

- When the toy is turned off, please hold the  button to turn Travel lock on/off. LED light flashes twice quickly.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and/or injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes and/or use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352