



Honey pot

Multi-speed vibration

Made from skin-like
TPR material and ABS
plastic

Power

- The item is powered by 3 AAA batteries.
- Open the lid to insert the batteries.
- Follow the polarity instructions inside the battery case.



3 AAA
batteries

How To Use

- Rotate the dial control to turn on/off.
- Adjust the dial control to increase/reduce the vibration intensity.



Cleaning and Care

- Take the sleeve out of the plastic case for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the sleeve before and after each use.
- Pat the sleeve with a towel and allow it to air-dry completely.
- Do not get water inside the case as it is not waterproof. Wipe it down with the wet cloth/tissue and dry it out completely before inserting the sleeve.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.

Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352