



## Hot Affair

PRODUCT MANUAL

---

**4 air pulse modes**

---

**10 vibrating modes**

---

**Magnetic clip**

---

**Remote-controlled**


---

**Made from silicone  
and ABS plastic**

## Charging

---

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge takes up to 1 hour for 2 hours of play.
- Do not use the device while charging.





Magnetic USB charging port





## How To Use


---

### Without remote control

- Hold the  button to turn the toy on/off. The LED light will flash.
- Press it quickly to cycle through 4 air pulse modes.
- Double press the  button to turn the vibration on/off.

### With the remote control

- Hold the  button on the toy to enter the standby mode.
- Press the  button on the remote to cycle through 10 vibrating modes.
- Hold it to pause the vibrating mode.
- Press the  button on the remote to cycle through 4 air pulse modes.
- Hold it to pause the air pulse mode.
- Hold the  button on the toy to turn it off.



## Cleaning and Care

---

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



## Warning

---

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

**edenfantasys**  
THE NEW INTIMACY

[www.edenfantasys.com](http://www.edenfantasys.com)

Customer Service  
10 AM - 7 PM EST  
Phone: +1 (770) 604 - 1352