ed@nfantasys



10 massage modes

Heats up to 104 °F

Realistic texture

Splashproof

Made from skin-like **TPE and ABS plastic**

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on)
- The intermittent glow indicates charging in progress.
- A full charge takes up to 1 hour for 1 hour of play.
- Do not use the device while charging.




charging port

PRODUCT MANUAL

How To Use

- Hold the button to turn the toy on/off.
- Press it quickly to cycle through 10 massage modes.
- Press it twice to turn the heating mode on/off.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with talc or cornstarch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.
- Store away from other toys to avoid chemical reactions and damage to either toy.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352