



Joy riding pillow

PRODUCT MANUAL

3 powerful motors

10 massage modes

5 massage intensities

Remote control

Inflatable pillow

Waterproof IPX7

**Made from silicone and
phthalate-free PVC**

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor, power bank or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 120 minutes for 60 minutes of play.
- Do not use the device while charging.




Magnetic USB
charging port

Before using






- Take out the cap from the toy's rear. Insert the tip of the pump into the hole and begin pumping to inflate it. Once the pillow is inflated as hard as desired, take the pump out of the hole. Then immediately press a finger to the hole to prevent the air from flowing out again. Quickly put the plug back into the hole of the pillow to seal it and keep the pressure inside.
- We advise you to blow up the pillow hard so it feels comfortable to sit on it. Alternatively, you can keep the pillow softer so it stays bouncy.
- Place the bottom of the vibrator in the notch of the pillow. Screw the vibrator part into the pillow.
- Screw the vibrator on (clockwise) for one and a half turns or until you feel it is firmly attached to the pillow.


How To Use

Without remote control

- Hold the  button on the bottom of the toy to turn it on/off.
- Press it quickly to cycle through 10 massage modes.

With remote control

- Hold the  button on the bottom of the toy to turn it on/off and put it in standby mode.
- Press the  button on the remote quickly to cycle through 10 massage modes.
- Press the  or  button quickly to cycle through 10 massage intensities.
- Hold it to save your favorite intensity level.
- Hold the  button to pause the toy.
- Press any button to reactivate the toy.



Power Button

Cleaning and Care

- Unscrew the vibrator counterclockwise to detach it from the pillow.
- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352