



# Joyful twist

PRODUCT MANUAL

---

## 5 vibration modes

---

Multi-speed

---

Realistic design

---

Splashproof

---

Made from silicone  
and ABS plastic

---

## Power

- The item is powered by 4 x AAA batteries (not included).
- Unscrew the base of the item to insert the batteries.
- Follow the polarity instructions inside the battery case.




4 x AAA  
batteries

## How To Use

---

- Hold the button to turn on/off.
- Press it quickly to cycle through 5 powerful modes.
- Adjust the dial-base to increase/reduce the vibration intensity.



## Cleaning and Care

---

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.



## Warning

---

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

**edenfantasy**  
THE NEW INTIMACY

[www.edenfantasy.com](http://www.edenfantasy.com)

Customer Service 24/7  
Phone: +1 (770) 604 - 1352