# ed@nfantasys



King g-orge

PRODUCT MANUAL

## 30 vibration modes

Soft curved G-spot tip

Made from silicone and ABS plastic

#### **Power**

- The item is powered by 2 AAA batteries
- Unscrew the base of the item to insert the batteries.
- Follow the polarity instructions inside the battery case.



#### **How To Use**

- Hold the **b** button to turn on/off.
- Press the W button quickly to cycle through 30 powerful modes.



### **Cleaning and Care**

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



## Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352