edénfantasys



Layla rabbit vibrator

PRODUCT MANUAL

7 vibration modes

3 rotating beads intensities

Two-way rotation

Bunny attachment

Waterproof

Made from silicone and ABS plastic

Power

- The item is powered by 3 AA batteries.
- Rotate the lid counter-clockwise to open the battery compartment.
- Follow the polarity instructions inside the battery case.



How To Use

- Hold the M button to turn on/ off.
- Press it quickly to cycle through 7 vibration modes.
- Hold the **()** button to activate/ deactivate rotation.
- Press it quickly to change the direction of the rotating beads.
- Press the ∧ or ∨ button to increase or reduce the intensity of the rotating beads.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: + 1 (770) 604 - 1352