edénfantasys



Levina Double End

PRODUCT MANUAL

Double penetration

2 powerful motors

30 massage modes

Realistic design

Waterproof

Made from silicone and ABS plastic

Power

- The item is powered by 2 AAA batteries.
- Unscrew the base of the toy to open the battery compartment.
- Follow the polarity instructions inside the battery case.



How To Use

- Press the 🙂 button to turn on/off.
- Press the **W** button quickly to cycle through 30 massage modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air dry completely.
- Use with water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

Customer Service from 10 AM to 7 PM EST. Phone: +1 (770) 604 - 1352

edén fantasys

www.edenfantasys.com