edénfantasys



- 10 massage modes
- **3 thrusting speeds**
- Strong suction cup
- Adjustable angle
- **Remote control**

Made from silicone and ABS plastic



PRODUCT MANUAL

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge for the sex machine takes up to 4 hours for 1 hour of play.
- Do not use the device while charging.

Magnetic USB charging port



Before Use

• Screw the machine to the suction cup base.



- Attach the suction cup stand to a smooth horizontal surface.
- Pull the latch clockwise to secure the suction cup.



Secure latch

- Adjust the angle.
- Tighten the knob to hold the position.
- Loosen the knob to change the angle. Tension knob



How To Use

Without remote control

- Hold the 🖒 button to turn on/off.
- Press it quickly to cycle through 10 massage modes.
- Press the + button to increase the thrusting intensity.
- Press the button to reduce the thrusting intensity.



With the remote control

- Insert 2 AAA batteries (not included) to power the remote control.
- Open the lid to insert the batteries.
- Follow the polarity instructions inside the battery case.
- Hold the 😃 button on the toy to activate the standby mode.
- Press the upper button on the remote quickly to cycle through 10 massage modes.
- The final push of the upper button turns the massage mode off.
- Press the lower button on the remote quickly to cycle through 3 thrusting intensities.
- The final push of the lower button turns the thrusting mode off.
- Hold the 🙂 button on the toy to turn the toy off completely.

Cleaning and Care

- Unscrew the machine from the suction cup base for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the shaft before and after each use.
- Pat with a towel and allow it to air-dry completely.

- Do not get water inside the corrugated part and control unit as they are not waterproof. Wipe them down with the wet cloth/tissue and dry it out completely.
- Use with water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.

Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352