edenfantasys



Love play

12 vibration modes

Remote-controlled

Made from PU-coated plastic

Power

- The item is powered by 3 LR44 batteries
- Unscrew the base of the item to insert batteries.



PRODUCT MANUAL

How To Use

- Insert 1 AAA battery to power the remote.
- Hold the remote's button to turn on/off.
- Press quickly to cycle through 12 vibration modes.



Cleaning and Care

- Use mild soap and water to clean the product.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube or silicone lubricant.
- The item can be sterilized with a 5% bleach solution or alcohol.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352