edénfantasys



Lust Egg

PRODUCT MANUAL

10 massage modes

Powerful motor

Discreet design

Splashproof egg

Made from Silicone and ABS plastic

Power

- The item is powered by 2 AAA batteries.
- Unscrew the lid of the control pack to open the battery compartment.
- Follow the polarity instructions inside the battery case.
- The 2 AAA batteries provide 2 hours of play.
- When storing for an extended period, please remove batteries from the device.



² AAA batteries

How To Use

- Press the U button to turn the toy on/off.
- Press it quickly to cycle through 10 massage modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Do not get water inside the egg and control pack as they are not waterproof.
- Use with water-based, silicone, or oil-based lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service from 10 AM to 7 PM EST. Phone: +1 (770) 604 - 1352