# ed@nfantasys



9 massage modes

2 powerful motors

Strapless design

Remote control

Waterproof

Made from silicone and ABS plastic

# Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on)
- The glow indicates charging in progress.
- A full charge takes up to 150 minutes for 90 minutes of play.
- Do not use the device while charging.
- The remote control is powered by 1 CR2032 battery (included).



USB charging port

Nana

### **How To Use**

#### Without remote control

- Insert the shorter shaft vaginally to aim and thrust the longer shaft.
- Hold the **b** button to turn the toy on/off. The LED light will light up.
- Press it quickly to cycle through 9 massage modes.

#### With the remote control

- Hold the button on the toy to enter the standby mode.
- Hold the **b** button on the remote to turn it on/off.
- Press the W button to cycle through 9 massage modes.
- Hold the button on the toy to turn it off.



## **Cleaning and Care**

- Use a toy cleaner/mild soap with water to clean the product before and after each use
- Pat with a towel and allow it to air dry completely.
- Use with water-based lube only, no silicone lubricants.
- Do not let the water get inside the remote control since it is not waterproof.
- Wipe the remote control down with a wet cloth/tissue and dry it out completely.



# **Warning**

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST

Phone: +1 (770) 604 - 1352