



## Nip treats

---

**7 rotation and  
massage modes**

---

**2 sets of attachments**

---

**Pleasure ticklers**

---

**Waterproof IPX7**


---

**Made from silicone  
and ABS plastic**

## Charging

---

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 1.5 hours for 1 hour of play.
- Do not use the device while charging.
- The remote is powered by CR2032 battery (included).




Magnetic charging port


## How To Use


---

### Without remote control

- Hold the  button to turn on/off.
- Press it quickly to cycle through 7 rotation and massage modes

### With remote control

- Remove the protective film from the battery compartment of the remote control before use.
- Hold the  button on the toy to activate the standby mode.
- Press the bottom **+** / **-** buttons on the remote quickly to cycle through 7 rotation and massage modes.
- Press **=** button on the remote to pause the vibration.
- Hold it to turn the remote off.



## Cleaning and Care

---

- Use a toy cleaner/mild soap with water to clean the toy before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.

## Warning

---

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

**edenfantasys**  
THE NEW INTIMACY

[www.edenfantasys.com](http://www.edenfantasys.com)

Customer Service from  
10 AM to 7 PM EST.  
Phone: 1 (770) 604 - 1352