



Adjustable strap

G-spot attachment

Vac-u-lock compatible

**Made from silicone,
ABS plastic and PU**



O-rider

How To Use

- Attach the dildo to the vac-u-lock plug and secure it.
- Slide your legs into the straps and adjust to fit your curves.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The dildo can be sterilized with a 5% bleach solution or alcohol.
- The dildo can be washed in a dishwasher.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352