



4 textured heads

Powerful vibration

Made from ABS plastic

Waterproof

O-Rocket

PRODUCT MANUAL

Power

- The item is powered by 1 AA battery.
- Unscrew the base of the item to insert the battery.



1 AA
battery

How To Use

- Rotate the dial control to turn on/off.



Dial base

Cleaning and Care

- Use mild soap and water to clean the product.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352